




1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19

+12V UNDER KEY  
(RED 1.5mm<sup>2</sup>)



1/86= +12V  
2/85= -  
5/87= OUT +12V



30= RED  
87= BLUE  
85= BLACK  
86= COLOR

FILE: Speedy-1200 Iprog\_2066-03

DIS. N.	MACCHINA/IMPIANTO	ORDINE	FOGLIO
CAD	Speedy-cutter 1200	COMMESSA	2
N. FILE	Rotair	ESECUTORE	SEQUE
POS. ARCH.	LOCALITA' Caraglio		
	DATA 07/10/10	AGG. 17/03/15	